

2M LAURICHEM



02057: Fat Water Moisturizing Toner featuring CLR Multimoist and Ethox Care Natural Chemistries.

INGREDIENT	INCI NAME	SUPPLIER	%W/W
PHASE A			
Di Water	Aqua, Water	Choice	72.70%
Holisurf HF	Glycolipids	2M Laurichem	0.50%
Genecare OSMS-BA	Betaine	IFF Health & Science	0.25%
Sodium Citrate	Sodium Citrate	Choice	0.10%
Butylene Glycol	Butylene Glycol	Choice	1.00%
Zemea	Propanediol	Dupont, Tate & Lyle	5.00%
PHASE B			
Glycerin	Glycerin	Choice	
Vanzan NF C	Xanthan Gum	Vanderbilt Minerals, LLC	6.00%
PHASE C			
ETHOXCARE® OCTG	Glycereth-18 Ethylhexanoate (and) Glycereth-18	2M Laurichem/Ethox	
ETHOXCARE® MG-20	Methyl Gluceth-20	2M Laurichem/Ethox	0.25%
Dowasil 2501 Cosmetic Wax	Bis-PEG-18 Methyl Ether Dimethyl Silane	Dow	2.00%
Dipropylene Glycol		Choice	2.00%
ETHOXCARE® G-26	Glycereth-26	2M Laurichem/Ethox	3.00%
NINOL C-5	PEG-6 Cocamide	Stepan	0.15%
Empigen BB	Lauryl Betaine	Innospec	0.15%
BP-Triluronic Acid	Water (and) Sodium Hyaluronate	Jeen	0.10%
Polysorbate 20	Polysorbate 20	Choice	0.75%
ETHOXCARE® G-10 MCC	Polyglyceryl-10 Caprylate/Caprato	2M Laurichem/Ethox	0.15%
MultiMoist CLR	Fructooligosaccharides (and) Beta Vulgaris (Beet) Root Extract (and) Water	2M Laurichem / CLR	3.00%
SPI-PQ51	Polyquaternium-51	Silicone Plus	0.25%
Gluconolactone SB	Gluconolactone (and) Sodium Benzoate (and) Calcium Gluconate	Making Cosmetics	1.50%
	TOTAL		100%

PROCEDURE

1. Add Phase A ingredients to main mixing beaker with shear mixing.
2. In a separate vessel, add Phase B ingredients a propeller mixer.
3. When Phase B is homogenous add to Phase A. Mix until the mixture is clear and thickened.
4. Add Phase C to the main mixture in order ensuring clarity after each addition. Mix until the mixture is homogenous.